

## C66



Waterproof Conductivity Tester with replaceable electrode (high range)

Rating: Not Rated Yet  
[Ask a question about this product](#)

Description

**C66 Waterproof Conductivity Tester with replaceable electrode (high range)**

The C66 is a conductivity IP65 waterproof tester, specifically designed for the hydroponics and Agricultural markets, with automatic temperature compensation and 1 point manual calibration. The tester has a range of 0.00 to 10.00 mS/cm.

The C66 has a replaceable electrode and is supplied in a casing with calibration solution sachets (M10031) and screwdriver for calibration. The modular design allows easy electrode and battery replacement.

Specification	C66
Range	0 to 10.00 mS/cm
Resolution	0.01 mS/cm
Accuracy	±2% Full Scale
Typical EMC Deviation	±2% Full Scale
Temperature Compensation	automatic from 5 to 50°C, with $\beta=2\%/^{\circ}\text{C}$
Calibration	manual, 1 point through trimmer
Probe	MA73076 (replaceable)
Environment	0 to 50°C; max RH 100%
Battery Type	3 x 1.5V; alkaline
Battery Life	approx. 250 hours of continuous use
Dimensions / Weight	165 x 30 x 30 mm / 80 g

**Accessories:**

- **MA73076** Replaceable Conductivity probe, HR
- **M10031B** 1413  $\mu\text{S}/\text{cm}$  calibration solution, 20 mL (25 pcs)

**Ordering information:**

C66 is supplied complete with protective cap, 20 mL 1413  $\mu\text{S}/\text{cm}$  sachet of calibration solution, carton box, calibration screwdriver, batteries and instructions.