

## MW605 MAX



MW605



Dissolved Oxygen / Temperature MAX Portable Meter

Rating: Not Rated Yet

[Ask a question about this product](#)

### Description

**MW605 MAX Dissolved Oxygen / Temperature Professional Portable Meter**

**MW605 MAX** is a portable, IP67 rated meter designed for fresh and saltwater measurements of dissolved oxygen (DO).

The MW605 meter is compatible with MA860 galvanic DO probe. Galvanic probes require no conditioning and thus the instrument is ready to measure when it is powered on.

Concentration measurements are automatically compensated for temperature and salinity. Temperature is automatically measured (in both degree Celsius and Fahrenheit) and compensated. Salinity and altitude can be configured in Setup.

Other features include:

- IP67 waterproof casing
- Auto-off feature to prolong battery life
- One or two % saturation calibration points at 100% (water saturated air) and 0% (zero oxygen solution)
- Dedicated GLP key to store and recall data on system status
- Available log space for up to 1000 records
- Logged data can be exported using a USB cable